

USER'S MANUAL



PORTABLE HIGH CURRENT TEST SET

MODEL NUMBER HC1

Version 5.1



Phenix Technologies, Inc
75 Speicher Drive
Accident, Maryland 21520

Copyright © Phenix Technologies, Inc.

Rev 8/23/2019 nab

HC-1

TABLE OF CONTENTS

<u>DESCRIPTION</u>	<u>SECTION NUMBER</u>
DANGER / GENERAL SAFETY PRECAUTIONS	
TECHNICAL SPECIFICATIONS	1
WARNINGS	2
CONTROLS AND INDICATORS	3
BASIC APPROACH TO TESTING	4
CALIBRATION	5
ELECTRICAL SCHEMATICS	6
PARTS LIST	7
PARTS ORDERING INFORMATION	8
RECOMMENDED SPARE PARTS	9
RETURNED MATERIAL	10
CUSTOMER COMMENTS / SUGGESTIONS	11

DANGER / WARNINGS

WARNING !!



DANGER

Grounding of this unit is necessary for the safe operation of this equipment. Disconnect inputs before ungrounding this equipment.

DANGER / WARNINGS

GENERAL SAFETY PRECAUTIONS



HIGH CURRENT

This equipment can produce POTENTIALLY LETHAL VOLTAGES and /or SEVERE BURNS! Improper operation or test practices may result in injury or death to the operator or surrounding personnel.

The operation of High Voltage test equipment should only be performed by personnel familiar with HIGH VOLTAGE testing and safety procedures. The operator of this equipment must be aware of all hazards associated with High Voltage testing. The operator is responsible for himself and others in close proximity of the testing area.

Some General Safety Practices for working with High Voltage Test Equipment have been listed below for your reference.

- **Become familiar with your instrument before performing an actual test**
- **Know your work area, check that all circuits are de-energized and locked out.**
- **Never work alone; always work with another qualified worker.**
- **Mark off entire work area with barriers and warning tape.**
- **Make all personnel aware of your testing activities.**
- **Be aware of dangerous conditions that may arise from energizing a test specimen.**
- **Never modify test equipment, modifications to equipment could introduce an unknown hazard or hinder a designed-in safety feature.**
- **DO NOT operate damaged equipment. Remove power, and do not use the equipment until safe operation can be verified by service-trained personnel.**

Phenix Technologies, Inc. assumes no liability for unsafe or improper use of test equipment.

TECHNICAL SPECIFICATIONS



The HC1 is a portable high current test set built for field and shop use. Designed using the latest technology, the HC1 combines a variable high current output with appropriate controls and instrumentation for testing thermal, magnetic, and solid-state motor overload relays, molded-case circuit breakers, and ground fault trip devices. The HC1 can be used in many other applications requiring a high current source.

The HC1 provides a short duration output of 1000 amps through a typical 150 ampere molded-case circuit breaker when an instantaneous trip element must be tested. Sufficient current is available for testing time delay characteristics of motor overload relays and molded-case circuit breakers.

The unique auto-sensing feature makes the HC1 easy to operate. Sensing leads, which operate on either normally open or normally closed (non-energized) devices, are connected to the test object auxiliary or non-energized contacts. The output current level can be easily pre-set. When the output is initiated, the pre-set output current locks on and the timer starts. When the test set senses a change in state of the test object auxiliary contacts (NO to NC or NC to NO), the current shuts off and the timer stops. If set to sense current, unit will shut current off at approximately 10% of range switch setting of currentmeter when test object goes open. For instantaneous trip tests, the memory feature of the currentmeter holds the peak current value until reset by the operator.

TECHNICAL DATA AND SPECIFICATIONS

INPUT:	120 Volts or 220 Volts 50 Hz or 60 Hz (must be preset)
OUTPUT:	0-120 Volts at 5 amperes 0-24 Volts at 25 amperes 0-6 Volts at 120 amperes 0-3 Volts at 240 amperes
OVERLOAD:	Short duration overloads are possible on each tap. The test set is capable of up to 1000 amps, depending on the impedance of the test circuit.
DUTY CYCLE:	Continuous at 100% 5 minutes ON/15 minutes OFF at 200% 1 minute ON/5 minutes OFF at 300% 30 seconds ON/5 minutes OFF at 400%
INSTRUMENTATION:	Currentmeter: 3 1/2 digit LCD Ranges: 0-1.999/19.99/199.9/1000 amperes Accuracy: +/- .5% Timer: 6 digit LCD, in cycles or seconds Ranges: 0-999999 cycles or 0-9999.99 seconds Accuracy: +/- 0.1% reading
DIMENSIONS:	21.25" W x 16.75" D x 13.75" H; 59 lbs. (220 V unit; 61 lbs.) (540 mm W x 426 mm D x 350 mm H; 26.8 kg) (220 V unit; 27.7 kg) Cables: 4 lbs. (1.8 kg.)
OUTPUT LEADS:	5 ft. sense control leads 5 ft. (#2) high current leads 5 ft. low current leads (10 Ga)


SECTION 2: DEVICE WARNINGS



1. For safe operation, it is important that the unit be plugged into a properly grounded receptacle.
2. This unit is **NOT** designed for use in energized circuits.
3. **WARNING:** Due to leakage current within the solid-state circuitry, it is **Strongly Recommended** to turn control power OFF when changing the output leads.
4. **NEVER** connect sense jacks to energized contacts or terminals being injected by test unit.

SECTION 3: CONTROLS AND INDICATORS

Control Panel



The following is a listing of the controls, switches, and lamps on the control panel and a description of their functions.

1. **POWER** This controls the input power to the control and the power section.
2. **Fuses:**
 - F1, F2 This protects the high-power circuits of the unit.
 - F3 This protects the variable transformer.
 - F4 This protects control circuitry and power supplies.
3. **HIGH CURRENT**
 - HC ON** When pressed, this allows current to flow from the unit (provided that the output is shorted as through a closed breaker). If this output current exceeds 10% of the selected output current range, the output will be maintained when the switch is released. Also, the **TIMER** will begin to run at this point.
 - HC OFF** When this is pressed, the output current will cease to flow from the unit.
 - JOG** This switch is used when it is desired to preset output current to a specific level. When pressed, the output current will begin to flow as it would when **HC ON** is pressed. The difference is that the **TIMER** will not begin running in this mode, and the output current will cease to flow when the switch is released, regardless of its magnitude.

CONTROLS AND INDICATORS

CONTROL PANEL (Cont'd)

- 4. RAISE CURRENT** Controls current level from minimum to maximum of output tap when HC ON or JOG is activated. Use with JOG to preset current level through test object.
- 5. TRIP/RESET** This switch serves several purposes.
- 1) When in CONTACTS mode, the lamp will illuminate to indicate that non energized contacts of the test specimen connected to the SENSE INPUTS has changed states.
 - 2) When in CURRENT mode, the lamp will illuminate to indicate that the output current has dropped below the 10% level.
 - 3) When pressed, the TIMER will be reset to zero.
 - 4) When the CURRENTMETER MEM/CONT is set to the MEM mode, pressing reset will release currentmeter from its highest registered reading. If the output current is not at zero, the present output reading will be maintained until either the output level increases, or the reset is pressed again.
 - 5) When illuminated, it must be pressed to reset controls for further operation.

6. SENSE

SWITCH

This can be set to CONTACTS or CURRENT mode. When placed in CONTACTS mode, the unit will react to a change in condition of the SENSE INPUTS. Upon a change in condition, the TIMER will stop running and the output current will cease to flow. The TRIP lamp will illuminate as an indication to the operator of a change in condition.

CAUTION: In CONTACTS mode, sense leads must be properly connected to non-energized contacts operated by the test specimen, or the timer will not shut off when the test specimen goes open. If the sense leads are not used, the sense switch must be in CURRENT position for proper functioning.

When the SENSE switch is set to the CURRENT mode, the unit will react to the output current dropping below 10% of the level of the selected current range.

INPUTS

These are connected to an auxiliary set of contacts (non-energized) regardless if they are normally open or closed. When RESET is pressed, the unit will remember its state. If the state changes, the unit will react to this change if the SENSE switch is set to CONTACTS.

CAUTION: Please do not attempt to connect these to the same set of contacts which you intend to energize, or to energized auxiliary contacts. This may cause damage to the unit.

CONTROLS AND INDICATORS

CONTROL PANEL (Cont'd)

7. CURRENTMETER This displays the RMS value of the output current level of the unit. Four ranges are available:

2 Amp	1.999
20 Amp	19.99
200 Amp	199.9
2000 Amp	1999

WARNING: Please note that there is no correlation between the currentmeter range switch setting and the rating of the taps.

8. MEM/CONT When set to the CONT (continuous) mode, the meter will continuously update to display the output current level. When placed in the MEM (memory) mode, the meter will retain the highest output current level achieved. If the level again exceeds this value, the meter will be updated. If you are below the highest level, pressing RESET will update the meter to the present level of output.

NOTE that the MEM mode of operation will only maintain the reading for a short time before the reading starts to decay.

9. TIMER The timer will begin counting when HC ON is pressed and the current surpasses the 10% level. The timer will stop when the current drops below the 10% level in the SENSE CURRENT mode. When in the SENSE CONTACTS mode, the timer will stop when a change in the SENSE INPUTS is detected.

The timer can be set to read CYCLES or SECONDS.

10. OUTPUT Connectors for the four outputs taps (0-120 Volts at 5 amperes) (0-24 Volts at 25 amperes) (0-6 Volts at 120 amperes) (0-3 Volts at 240 amperes).

SECTION 4: BASIC APPROACH TO TESTING



The HC1 is basically a continuously variable high current source, the magnitudes of which are dependent on the output tap which is selected. Please refer to the Technical Data and Specifications for the voltage and current ratings of the taps.

The output current is controlled by use of the RAISE CURRENT knob on the control panel. By turning the knob in the clockwise direction, the current is raised. By turning the knob in the counterclockwise direction, the output magnitude is decreased.

The RMS value of the output current is displayed on the CURRENTMETER. If the MEM/CONT switch is in the CONT (for CONTinuous), the meter displays the real-time value of the output. If the MEM/CONT switch is in the MEM (for MEMory), the highest value of the output current is displayed.

When a breaker is to be tested, the operator may select the SENSE CONTACTS mode or the SENSE CURRENT mode of operation. If an auxiliary set of non-energized contacts are available, the SENSE CONTACTS mode may be selected. By pressing JOG or RESET, the state of the contacts (be it normally open or normally closed) are remembered by the unit. The operator may then preset the output current to the desired level by use of the JOG switch. When this is done, by pressing HC ON (and assuming that the current level exceeds 10% of the CURRENTMETER range selected), the current will continue flowing after the switch is released and the TIMER will begin to run.

When the contacts connected to the SENSE INPUTS change state, the TIMER will stop running and the output current will cease to flow. The TRIP lamp will illuminate as an indication to the operator. If the MEM/CONT switch is in the MEM mode, the highest output current achieved will be displayed on the CURRENTMETER. The operator should note this level before the readings begin to decay. Pressing RESET will zero the TIMER and CURRENTMETER readings and prepare the unit for operation again.

When the SENSE switch is set to the CURRENT mode, the SENSE INPUTS are not used. This position was meant mainly for single pole breakers in which the SENSE INPUTS cannot be used. In this mode, initiation of the test is the same as in SENSE CONTACTS mode. The difference is the completion of the test. When the output current falls below 10% of range (as when the contacts of the breaker open), the TIMER stops running and the output current turns off. The TRIP lamp illuminates as an indication to the operator.

SECTION 5: CALIBRATION

TIMER The timer is run from a precision programmable oscillator and should never require calibration.

CURRENTMETER The calibration of the currentmeter should be checked annually.

To do this, place the MEM/CONT switch in the CONT position. Place the range switch in the 2 AMP range. With nothing connected to the output and the RAISE CURRENT knob in its fully counterclockwise position, adjust R10 until the CURRENTMETER reads zero. With appropriate test equipment (RMS), raise the output current to 80% of each range, and adjust the corresponding calibration potentiometer to agree with your standard (40% or 800A on 2000 Amp range for HC1).

2 Amp	R84
20 Amp	R85
200 Amp	R69
2000 Amp	R73

SECTION 6: ELECTRICAL SCHEMATICS

<u>Drawing Number</u>	<u>Description</u>
1. 9304500	HC-1 Electrical Schematic (120V)
2. 9304501	HC-1 Electrical Schematic (220V)

SECTION 7: HC-1 PARTS LIST

Item	Part No.	Description	QTY
	1350104	SPCR -32 X 1/2 ALUM 1/4 HEX	4
	1077143	14/3, SJT, 8'PWR CORD (1FD92)	1
	1150944	3420-8, BUSHING 8(16)	1
	1152210	1-640440-0, CON 10CKT.1	1
	2100507	CASE GH1519-RM-2 (01100528)	1
	1159951	1/2" ROMEX CONN. #3301	1
	1351100	BINDING POST 459 BLACK	1
	1351102	BINDING POST 459-102 RED	2
	1351111	PIN JACK 39F1562	2
	1351112	PIN PLUG BLACK	2
	1352120	2GA 1/4" HOLE ILSCO LUG# CSWS-1-14	1
	1352121	ILSCO CRA-1 2GA-3/8	5
	1352130	2/0 3/8" HOLE ILSCO LUG# CSWS-3/0-38	4
	1353001	GATOR BT, 62B, BLK	2
	1353002	GATOR CLIP, 60CS -10Amp	2
	1353040	GATOR BT, 29 LG, RED	1
	1353041	GATOR BT, 29 LG, BLK	1
	1353042	GATOR CLIP, 27C -20Amp	2
	2101710	HANDLE (SMALL), 10501-005, 3RU	2
	40400042	HC1, HC2, DIVIDER PANEL	1
	40400041	HC1, HC2 CHASSIS	1
	50100012	WIRING HARNESS ASSY FOR PCB 1361	1
	2980265	2-3/4" x 3" PHENIX LOGO	1
CT1	1892206	CURRENT TRANS. 1000/1	1
F.P.	42000037	CONTROL PANEL, HC1	1
F1-4	1603920	#345613A 1P PNL MNT FUSEHLDER (3 AG)	4
F1-F3	1603629	MDA 20 SLOW BLOW FUSE (120V)	3
F1-3	1603625	MDA 10 SLOW BLOW FUSE (220V)	3
F4	1603603	AGC-3 (120V)	1
F4	1603602	AGC-1.5 (220V)	1
J1, J2	1151955	JUMPER-JAX ROHS	2
M1	1506400	KNS DMO-66PHX 3 1/2 DIG LCD	1
MOV1,2	1606100	MOVISTOR V130LA10A (120V)	2
MOV1-2	1606110	MOVISTOR V275LA40A (220V)	2
PS1	1590110	PS 5VDC,5A, SW-OPEN FRAME	1
R200,201	1741990	10W, 1K, 1% WIREWOUND	2
SSR1	1700340	RELAY SOLID STATE 25A 120V	1
SW1,3,4,5	1420143	10-1307.1369 EAO LAMP 6.3V	4
SW1,4	1422150	31-903.2 LENS, EAO RED	2
SW1,3,4,5	1860120	31-121.025 EAO, MOM. 1POLE	4
SW2,8,9	1865010	MPC223 PCB TOGGLE	3

HC-1 PARTS LIST

Item	Part No.	Description	QTY
SW3	1422152	31-903.4 LENS, YELLOW	1
SW5	1422151	31-903.5 LENS, GREEN	1
SW6	1355310	KNOB PKAP-50B-1/4	1
SW6	1863047	ROTARY SW 2P 2-6 POS-S (10WA355)	1
SW7	1865005	C-H7565K7 TLG 2PDT	1
T1	1890201	STACO 1010B VARIAC (120V)	1
T1	1890204	1020B VAR. STACO (220V)	1
T1 SHAFT	0400162	VARIAC SHAFT, BK SERIES	1
T2	8321164	GA1-1164	1
TIMER	1505421	BEZEL KIT HWK30000/ HWK-30-000/A	1
TIMER	1505420	MDMU0000 RED LION COUNTER/TIMER	1
OUTPUT PNL	40400174	HC1 OUTPUT PANEL	1
PCB1223	31122305	PCB1223 ASSY FOR HC 0.3,1,2,3	1
PCB1361	31136100	PCB1361 HC CONTROLS AND PWR ASSY	1

SECTION 8: PARTS ORDERING INFORMATION

Replacement parts are available from Phenix Technologies, Inc.

Changes to Phenix Technologies' products are sometimes made to accommodate improved components as they become available, and to give you the benefit of the latest technical improvements developed in our Engineering Department. It is, therefore, important when ordering parts to include the serial number of the unit as well as the part number of the replacement part.

When your purchase order is received at our office, a representative of Phenix Technologies will contact you to confirm the current price of the part being ordered. If a part you order has been replaced with a new or improved part, an applications engineer will contact you concerning any change in part number.

Send orders for replacement parts to:

**Service Department
Phenix Technologies, Inc.
75 Speicher Drive
Accident, Maryland 21520**

**Ph: 1 (301) 746-8118
Fax: 1 ((301) 895-5570
E-mail: info@phenixtech.com**

SECTION 9: RECOMMENDED SPARE PARTS

Phenix Technologies recommends that the customer purchase and stock the following parts for normal maintenance of the unit. The recommended quantity should be sufficient to support the unit during normal operation.

If the unit will be operated at an isolated site for an extended period or will be subjected to unusual stresses, a larger quantity of parts should be stocked as spares. In such cases, contact Phenix Technologies for a recommendation.

Current prices may be obtained by contacting the Service Department at Phenix Technologies.

<u>Part Name</u>	<u>Computer Number</u>	<u>Recommended Quantity</u>
Lamps, 6.3, EAO	1420143	4
EAO Momentary – 1 POLE Switch (SW1, 3, 4, 5)	1860120	1
Switch, Main Power (SW7) 2 PDT	1865005	1
Binding Post – Red	1351102	1
Binding Post - Black	1351100	1
Fuse Holder – 3 AG	1603920	1
F1, F2, F3 (120V) - MDA 20 Amp Slow Blow	1603629	6
F1, F2, F3 (220V) – MDA 10 Amp Slow Blow	1603625	6
F4 (120V) 3 AG 3 Amp	1603603	1
F4 (220V) 3 AG 1.5 Amp	1603602	1
Current Meter – KNS 3 ½ digit	1506400	1
Timer – Red Lion Sub- Cub - D	1505420	1
Lens – Red EAO	1422150	1
Lens – Green EAO	1422151	1
Lens – Amber EAO	1422152	1

SECTION 10: RETURNED MATERIAL

If for any reason it should become necessary to return this equipment to the factory, the Service Department of Phenix Technologies, Inc. must be given the following information:

Name Plate Information

Model Number

Serial Number

Reason for Return

Cause of Defect

If Phenix Technologies, Inc. deems return of the part appropriate, it will then issue an "Authorization for Return."

If return is not deemed advisable, other inspection arrangements will be made.

NOTE: Material received at this plant without the proper authorization shall be held as "Customer's Property" with no service until such time as the proper steps have been taken.

Your cooperation is requested in order to ensure prompt service.

SECTION 11: CUSTOMER COMMENTS/SUGGESTIONS

Phenix Technologies made significant efforts to ensure that the materials in this Operator's Manual are correct. If there are concerns or comments as you have used this information, Phenix Technologies appreciates any feedback.

Unit Serial Number:

Sect	Page(s)	Comment

Please return to Phenix Technologies, Engineering Department, 75 Speicher Drive, Accident, MD 21520 USA.

Phone: 1 (301) 746-8118, Fax: 1 (301) 895-5570 or Email: info@phenixtech.com